

# LUMBER ARMOR

Classic Style Wrap



## Instructions:

- 1) Start by placing the front panel, using your device screen for reference. There should be an even amount of space on all sides of the screen and allow for a panel overhang on all sides of the bezel
- 2) (Optional - to aid with future removal) Before placing the back panel, put it on a piece of clothing to reduce adhesive tack slightly.
- 3) Align back panel and place on device, leaving a small overhang on all sides- similar to the front
- 4) Begin wrapping the side strip at the SIM card slot or volume buttons, use two fingers to align it evenly between the front and back panels
- 5) Wrap the side strip around your device and complete the wrap, matching the two sides of the clasp closely
- 6) Choose your buttons and place on your device

Notes: All panels allow a few minutes for careful adjustments before the adhesive becomes more secure. If you need to adjust the front or back panels, go against the grain to remove (with the grain for the side strip). The side strip will align itself with the button spacing, there should be no need to force it but there is some room for adjustment in places like the SIM, power button or clasp.

We offer replacements panels for \$2 or you can get our protection plan for \$10 that will replace up to 3 full wraps. Please contact us at [info@studioeqdesign.com](mailto:info@studioeqdesign.com) with your order # to redeem. Thanks!