


THANK YOU LUMBER ARMOR



INSTALLATION INSTRUCTIONS

- 1.** After removing from packaging, start by peeling the backing from the side strips. When your phone is clean and you're ready to wrap it, remove the rest of the backing.
- 2.** Start by aligning the front panel, using your screen for reference. There should be an even amount of space on all sides of the screen.
- 3.** Wrap the top / back piece around the top of your phone, aligning the cut-outs with your camera. Some small cracking may occur, we recommend smoothing them out with a pen or fingernail.
- 4.** Wrap the bottom / back piece around your phone, matching up the port holes as you go.
- 5.** Complete by wrapping the side strips and adding your button and camera covers. Two options are provided, one with icons, one clean.

TO REMOVE Do your best to warm up the wrap thoroughly with your hands, the sun, or with a hair dryer. Start with the screen and try to remove in one piece.

OPTIONAL (to aid in future removal): Place panel(s) on a piece of clothing prior to installation to reduce adhesive tack slightly. We offer a low-cost replacement program if you need to remove your wrap for repairs or experience excessive wear.

