

Thank you!

Stealth iPhone Wrap Instructions



100% Recyclable - 1-piece Design Use 3M Adhesive - Made from Sustainable Materials
Low-Cost Replacements for 6 months - Made in Venice, CA



1. Remove from box & clean phone



2. Peel the 4 small tabs first then remove from either side



3. Use screen to align*



4. Wrap the side panels to meet in the back



5. Roll the top & bottom



6. Fold the 4 tabs, add buttons and you're done!



*Optional but recommended: To aid in future removal, once the front screen is aligned, place the exposed panels on a garment or fabric a couple times to reduce adhesive tack.



made in USA

To remove: Warm up the adhesive as best as possible, place your phone in the sun for a few minutes or use a hairdryer

patent pending

www.LumberArmor.com